

SAT Phone Operation



Aircraft phone numbers

632CP: 1-254-241-0850

157CP: 1-254-204-0447

Most important items

1. “Tel” button on Com panel must be on to make and receive calls
2. **NEVER** use the PTT switch, simply answer the phone by pushing the “hook” button and speaking

Buttons:

1. **Hook:** used to initiate and receive a call – analogous to lifting the receiver on a telephone
2. **Hold:** used to put a call on hold
3. **Number/symbol keys:** used to dial a phone number analogous to a telephone – always dial the complete number including “1” and the area code.
4. **Redial:** recalls and dials the last number dialed (cleared when power is turned off)
5. **Flash:** allows user to interrupt a call and deal with a second call, analogous to call waiting (if in service)
6. **Vol:** press upper portion several times to increase volume, lower portion to decrease volume. There are 32 steps.

To initiate a call:

1. Com panel “TEL” button – push on
2. Hook button – push to receive dial tone
3. Keypad – dial phone number (1-xxx-xxx-xxxx)
4. When party answers – talk

To answer a call:

1. Com panel “Tel” button must be on
2. Phone will ring
3. Press “hook”
4. Talk – do not use the aircrafts PTT switch